



# LIFTS

## sigma4lifts

Connected lifts

Access the **IoT platform** for **remote management** | Get visual information on your **geolocated lifts** | Manage **user profiles** | **Generate log reports** in PDF and HTML | Get access to **demo videos** on how to use the platform

- Encrypted data exchange - Compliance with the requirements of new European safety standards for IoT devices.
- VPN connection for a secure intranet.
- Use of secure servers.
- Access to the coverage agreements MP has in place with a technology company.
- Access to remote technical support from MP in the event of faults.



Get information on the key **metrics** for lifts

Current incidents and logs of **faults**, alarms and errors generated during test calls



**Alerts**: warnings when a parameter deviates from its normal operating value



Changes to a lift's **status**: inspection, normal, out of service, etc.



Information: general **messages** on lifts

### emergency service

#### FEATURES

Remote emergency alarm management in accordance with EN 81-28:2018

#### Technical features

Log of emergency and test calls carried out every 72 hours

MP ecoGO

Via serie

MicroBasic



### plus service

#### FEATURES

#### Technical features

			MP ecoGO	Via serie	MicroBasic
<b>FOTA</b>	Firmware updated remotely	Remote firmware updates	✓	✗	✗
<b>STATUS</b>	Real-time monitoring of lifts	Car position	✓	✓	✓
		Door status	✓	✓	✓
		Car at landing	✓	✓	✓
		Status of safety devices	✓	✓	✓
		Information on the lift's main parameters (programming console)	✓	✓	✓
		Status of pre-final limit switches	✓	✓	✓
		Advanced real-time monitor: % battery power left, position in mm, etc.	✓	✗	✗
<b>REMOTE CONTROL</b>	Remote commands	Lifts can be called from the control operating panel	✓	✓	✓
		Lifts can be called from the landing operating panel (up/down)	✓	✗	✗
		Control board reset	✓	✓	✓
		Force alarm/test/low battery call	✓	✗	✗
		Information on operating mode	✓	✗	✗
<b>PREVENTIVE</b>	Preventive measures based on data analysis	Statistics	✓	✗	✗
		Log of events	✓	✗	✗
<b>NOTIFY</b>	Choose to receive alarm and event alerts	Notification of errors, changes to status and entrapment alarms	✓	✓	✓
<b>SETUP</b>	Adjustment of lift parameters	Adjustment of general parameters	✓	✓	✗
		Adjustment of all parameters	✓	✗	✗
<b>IDENTIFY</b>	Identification of versions of hardware and software	Information obtained remotely on versions of hardware and software for all the boards of a lift	✓	✗	✗
<b>TRAFFIC CONTROL</b>	Trip counter	Tracking of the number of travel cycles made each day	✓	✗	✗
<b>MULTIMEDIA</b>	Remote customisation of the information and image featuring on the car's TFT display	Images   Text messages   RSS feed configuration	✓	✗	✗
<b>Callmylift app</b>	Contactless destination selection	Activation of remote calls from mobile phones	✓	✓	✓
<b>MyLift</b>	Access to information of interest for owners	Current incidents and logs of faults, alarms and errors generated during test calls	✓	✓	✓